



## DECTEC WALL TRANSITION AT FIBER CEMENT SIDING W/ RAINSCREEN

**NOTES:**

1. INSTALLATION TO BE COMPLETED IN ACCORDANCE WITH MANUFACTURERS SPECIFICATIONS.
2. DO NOT SCALE DRAWINGS.
3. MIN. SLOPE 1/4":12" AWAY FROM STRUCTURE.
4. DECTEC MEMBRANE / FLASHING TO BE FULLY ADHERED ON ALL VERTICAL FLASHINGS WITH SBA 100.
5. PLYWOOD SUBSTRATES TO BE EXTERIOR GRADE MIN. 5/8" T&G OR ALTERNATIVELY MIN. 5/8" WITH ALL PLYWOOD JOINTS BLOCKED FROM BELOW.
6. AS A SUPPLIER OF MATERIALS ONLY, SKYLINE BUILDING SYSTEMS INC. DOES NOT ASSUME RESPONSIBILITY FOR ERRORS IN DESIGN, ENGINEERING, QUANTITIES, OR DIMENSIONS. THE ARCHITECT, CONTRACTORS, OR OWNERS REPRESENTATIVE MUST VERIFY ALL DIMENSIONS, SIZES AND SUITABILITY OF DETAILS.